

# Primer-P

*For Insta-Clay*



---

November 2005

## Primer for Insta-Clay Gilding

---

Kölner-GlanzGold-Grund developed Primer-P, a water-based sealer specifically designed for sealing porous surfaces, to produce a strong bond between the wood substrate and layers of **Insta-Clay**.

---

### **Primer-P** for Insta-Clay

Primer-P produces a strong bond between raw wood and Insta-Clay. Its chemical structure seals the wood and creates a link with the layers of Insta-Clay. Upon drying, it is insoluble in water.

Primer-P should be used at package consistency. Generally, one coat is sufficient for most wood surfaces. However, if one coat dries to a glossy sheen, thin with water to a maximum of 20%. Highly porous materials, such as plaster, might require two to three coats which should be applied **wet on wet**. Allow to dry completely before applying Insta-Clay.

Average drying time - One hour.

Available in pints, quarts and gallons.

May be applied with a HVLP sprayer if thinned with water 10-15% by volume.

Clean brushes with soap and water.

If Primer-P has dried, use acetone to clean tools.

Always test all products and procedures to determine end results.